

Enviromec

"Build to specification" Options - for static hot water models

Time Out - Machine automatically cuts out after a pre-determined period of time. Allows operator to perform tasks within the timed period.

Auto Stop - The machine automatically switches off directly after use.

Frost Protection - Lining of the cabinet to protect against frost in mild frost conditions.

Frost Stat - Thermostat and heater that automatically switches on in frost conditions, to protect the unit in harsher frost conditions.

Auto Chemical - Detergent system can be automatically operated by either token operation, changing lances, or reducing the working pressure.

Auto Foam - Addition of air into a special detergent to produce a foam for longer contact time and to reduce detergent waste.

Satellite Switching - A remote box fitted away from the unit, and usually closer to the working area.

Integral Fuel Tank - An internally fitted fuel tank where a supply of fuel is not available.

Restricted Switching - Settings for pressure, detergent amount, temperature etc are fitted and locked inside the cabinet, allowing operators only basic pre-set options.

Coin Operation - Coins or tokens used to operate the machine, to allow monitoring or charging out of running costs.

Key Pad - Numerical key pads so operators need pin numbers to operate the machine, selective usage of features, and to allow monitoring of usage.

Swipe Start - A swipe card is required to allow operator usage.

Colour Code - Colour coded lances that give the operator different settings of pressure or detergent etc and allows restriction of operator usage.

Services Connection - Direct connection to mains power, water and services to prevent operator abuse.

Exhaust Connection - Fitting of an exhaust flue to vent any fume from the unit inside buildings where there is a requirement to do so.